

# FRICD


Original instructions






#### Scand






## Minimum distance




### Connections W

Top view of the top (connections from above)



Top view of the bottom (connections from below)




## Connections E 💈

Top view of the top (connections from above)


Top view of the bottom (connections from below)



Distance water connections - end



## Open unit




FC Frico Control

PC board FC is integrated within the air curtain at delivery.



Item number	Туре	
FE10129	SFFEH	100-1000 mm
330955	FH1025	DN25, 1", 1000 mm



SFFEH




C

## Valve systems


Item number	Туре	DN	Flow range [l/s]
238293	VPFC15LF	DN15	0,012-0,068
238294	VPFC15NF	DN15	0,024-0,13
238295	VPFC20	DN20	0,058-0,32
238296	VPFC25	DN25	0,10-0,60
238297	VPFC32	DN32	0,22-1,03
<u></u>	4 I		

See separate manual.




## Control systems

The air curtain must be supplemented with a control system.



Item number	Туре	Name	Dimensions
74684	FCDA	FC Direct	89x89x26 mm (FCCF)
74685	FCSA	FC Smart	89x89x26 mm (FCCF)
74686	FCPA	FC Pro	89x89x26 mm (FCCF)
74687	FCBA	FC Building	89x89x26 mm (FCCF)

#### Accessories



Item number	Туре		Dimensions		
74694	FCRTX		39x39x23 mm		
74695	FCOTX		39x39x23 mm		
74699	FCLAP		89x89x26 mm	FCWTA FCDC	
74702	FCWTA	SFFEC W			
17495	FCDC				!
74718	FCBC05		5 m		
74719	FCBC10		10 m		
74720	FCBC25		25 m	FCBC05/10/25 FCTXRF	
74721	FCSC10		10 m	FCSC10/25	
74722	FCSC25		25 m		
74703	FCTXRF	for FC Smart, FC Pro	89x89x26 mm		

See separate manual for FC.

## **Technical specifications**

Item number	Туре	Output steps [kW]	Airflow*1 [m³/h]	∆t*4 [°C]	Sound power* <sup>2</sup> [dB(A)]	Sound pressure* <sup>3</sup> [dB(A)]	Amperage motor [A]	Voltage [V] Amperage [A](heat)	Weight [kg]
FE10240	SFFEC4E16	5,4/11/16	1850/3600	26/13	82	48/66	4,1	400V3~/24	70
FE10242	SFFEC6E24	7,8/16/24	2300/4700	30/15	83	50/67	6	400V3~/34	75

#### f Electrical heat - SFFEC E (IP20)

#### Water heat - SFFEC WL (IP20)

Item number	Туре	Output*⁵	Output*6	Airflow*1	$\Delta t^{*4,5}$	$\Delta t^{*4,6}$			Sound pressure* <sup>3</sup>		Weight
		[kW]	[kW]	[m³/h]	[°C]	[°C]	[1]	[dB(A)]	[dB(A)]	[A]	[kg]
FE10241	SFFEC4WL	21	36	1650/3300	24/19	40/32	4,4	80	47/64	4,1	80
FE10243	SFFEC6WL	26	44	2200/4600	22/17	37/28	4,4	81	47/65	6	90

Voltage motor: 230V~ Height\*7: 2200 mm

\*1) Low/high airflow (2V/10V).

 $*^{2}$ ) Sound power (L<sub>wA</sub>) measurements according to ISO 27327-2: 2014, Installation type E.

\*<sup>3</sup>) Sound pressure (L<sub>pa</sub>). Conditions: Distance to the unit 5 metres. Directional factor: 2. Equivalent absorption area: 200  $m^2$ . At low/high airflow (2V/10V).

 $^{*4}$ ) Δt = temperature rise of passing air at maximum heat output and low/high airflow (2V/10V).

\*5) Applicable at water temperature 60/40 °C, air temperature, in +18 °C.

\*6) Applicable at water temperature 80/60 °C, air temperature, in +18 °C.

\*<sup>7</sup>) Standard height. Max. height 3000 mm (extension without fans).

\*<sup>5,6</sup>) See www.frico.net for additional calculations.

## Product key

Type - Connection position - Total height - Material / Colour Example: SFFEC4WL - A - 2800 - P

Туре	See Technical specifications.	
Connection position*	A = from above B = from below	
Total height	Min. height 2200 mm. Max height 3000 mm. Extension without fans	
Material / Colour	P = Polished stainless steel B = Brushed stainless steel MP = Mirror polished stainless steel State RAL code = Powder coating RAL State NCS code = Powder coating NCS	

Contact Frico before ordering for more information about the product and special adaptations.

#### **EN Connection position\***


SE Anslutningsposition NO Tilkoblingsposisjon

- ES Posición de la conexión
- DE Position der Anschlüsse
- RU Место подключений FR Position du raccord
- - NL Positie aansluitingen
- PL Położenie złączy

IT Posizione di collegamento

DK Tilslutningsposition

SFFEC E




## Wiring diagrams for control system in the FC manual.

8

Scand

Scand

## SFFEC W



Wiring diagrams for control system in the FC manual.



## Installation and operating instructions

#### **General Instructions**

Read these instructions carefully prior to installation and use. Keep this manual for future reference.

The product may only be used as set out in the assembly and operating instructions. The guarantee is only valid should the product be used in the manner intended and in accordance with the instructions.

#### Application

Scand is a vertical air curtain specially designed for revolving doors, with a curved design that integrates neatly with the door. The air curtain is available with electrical heating and with water heating.

Protection class: IP20.

#### Operation

Air is drawn in at the side of the unit and blown out against the entrance, so that it shields the door opening and minimizes heat loss.

The grille for directing exhaust air is adjustable and is normally angled towards the revolving door to achieve the best protection against incoming cold air.

The efficiency of the air curtain depends on the air temperature, pressure differences across the doorway and any wind pressure.

NOTE! Negative pressure in the building considerably reduces the efficiency of the air curtain. The ventilation should therefore be balanced.

#### Mounting

The air curtain is vertically mounted to the left of the door seen from inside. Air curtains for installation to the right can be specially ordered. The unit has a curved design which makes it an integrated part of the door. Standard length is 2200 mm. Lengths up to 3 m can be ordered according to the product key (extension without fans). Extension hoods, for heights up to 4 m, are available as an accessory.

The air curtain is installed on adjustable feet which makes it possible to compensate for any surface undulations. The feet are attached to the floor with fasteners appropriate to the surface and covered by a frame. Fasteners are not included.

The air curtain must always be secured at the top. The M8 press nut on the top of the unit is used for this, see figure.

The product must be mounted in such a way as to allow future service and maintenance.

When mounting a product in stainless steel, the protective plastic shall remain on the product. The plastic is removed only when mounting and installation are completed. Be careful to not damage the surfaces.

#### **Electrical installation**

The installation, which should be preceded by an isolator switch with a contact separation of at least 3 mm, should only be wired by a competent electrician and in accordance with the latest edition of IEE wiring regulations.

The air curtain has an integrated PC board which is connected to the selected external control system FC. FC must be ordered separately. FC is supplied pre-programmed. Communication and sensor cables are connected to the PC board.

Should more than one air curtain be controlled by a single FC, an additional communication cable FCBC per unit will be required. See manual for FC.

Control is supplied by 230V~ to the PC board. The PC board is placed in the top of the unit and is accessed via cable glands on the top or bottom of the unit. Pierce the grommet with a screwdriver before entering the cable. Cables to the PC board should be routed through the unit when the connection is made from the bottom. Bundle the cables inside the unit to prevent that they will be drawn into the fans or get in contact with the heating elements.

For units with electrical heating, the power supply for heating (400V3~) is connected to the terminal block. The electrical connection may be done from above or below, according to ordering key. Connections made from below the unit must be prepared in the floor according to the drawing.

The largest cable diameter for the terminal block is 16 mm<sup>2</sup>. The cable glands used must meet the protection class requirements. In the distribution board, it is to be indicated that "the air curtains can be supplied from more than one connection".

Туре	Output Voltage		Minimum area*
	[kW]	[V]	[mm <sup>2</sup> ]
Control	0	230V~	1,5
SFFEC4E16	16	400V3~	6
SFFEC6E24	24	400V3~	10

\*) Dimensioning of external wiring shall comply with applicable regulations and local deviations may occur.

#### Start-up (E)

When the unit is used for the first time or after a long period of non-use, smoke or an odour may result from dust or dirt which has collected on the element. This is completely normal and disappears after a short time.

#### Connecting the water coil (W)

The installation must be carried out by an authorised installer.

The water coil has copper tubes with aluminium fins and is suitable for connection to a closed water heating system. The heating coil must not be connected to a mains pressure water system or an open water system.

Note that the unit shall be preceded by a regulating valve, see Frico valve kit.

Valves must be installed outside the unit. Note that the actuator needs power supply and control signal from the integrated PC board.

The water coil is connected on the top or the bottom of the unit via connections DN25 (1''), internal thread. See product key.

Connections made from below the unit must be prepared in the floor according to the drawing. Note the distance between the water connections and the end of the unit. See figure. Flexible hoses are available as accessories.

NOTE: Care must be taken when connecting the pipes. Use a pipe wrench or a similar

tool to grip the air curtain connections to prevent straining of the pipes and subsequent water leakage during connection to the water supply pipe-work.

The connections to the heating coil must be equipped with shut off valves to allow troublefree removal.

The coil is equipped with air valves.

#### Adjustment of the air curtain and airflow

The direction and speed of the airflow should be adjusted considering the load on the opening. Pressure forces affect the airstream and force it inwards towards the premises (when the premises are heated and the outdoor air is cold).

The airstream should, therefore, be directed outwards to withstand the load. Generally speaking, the higher the load, the greater the angle required.

Protection of the exposed area just above the floor is essential, motors are placed from the bottom up. The airflow can therefore be slighly less at the top of unit.

#### **Basic setting fan speed**

The fan speed when the door is open is set using the control. Note that the airflow direction and the fan speed may need fine adjustment depending on the loading of the door.

#### Filter (W)

The distance between the coil plates in combination with the hole diameter of the intake grille protects against dirt and blockage. This normally makes a separate filter unnecessary.

#### Service, repairs and maintenance

For all service, repair and maintenance first carry out the following:

- 1. Disconnect the power supply.
- 2. The service hatch is opened by removing the screws on the side of the unit.

#### Maintenance

Since fan motors and other components are maintenance-free, no maintenance other than cleaning is necessary. The level of cleaning can vary depending on local conditions. Undertake cleaning at least twice a year. Inlet and exhaust grilles, impeller and elements can be vacuum cleaned or wiped using a damp cloth. Use a brush when vacuuming to prevent damaging sensitive parts. Avoid the use of strong alkaline or acidic cleaning agents.

Vacuum the intake grille regularly from outside when dust is visible, for example as a part of the cleaning routine.

#### **Temperature control**

Temperature control of FC maintains the exhaust temperature. Should the temperature exceed the preset value, the overheating alarm will activate. For more information see the FC manual.

#### Overheating

The air curtain unit with electrical heating is equipped with an overheat protection. If it is deployed due to overheating, reset as follows:

- 1. Disconnect the power supply with the isolator switch.
- 2. Allow the electrical coil to cool.
- 3. Determine the cause of overheating and rectify the fault.
- 4. Reconnect the unit.

11



## Replacing heating elements/heating package (E)

- 1. Mark and disconnect the cables to the heating elements/package.
- 2. Remove the mounting screws securing the heating elements/package in the unit and lift the heating elements/package out.
- 3. Install the new heating elements/package in reverse order to the above.

#### Replacing the water coil (W)

- 1. Shut off the water supply to the unit.
- 2. Disconnect the connections to the water coil.
- 3. Remove the mounting screws securing the coil in the unit and lift out.
- 4. Install the new coil in reverse order to the above.

#### Safety cut-out

All motors are equipped with an integrated safety cut-out. This will operate, stopping the air curtain should the motor temperature rise excessively or the electronics fail or overheat. The cut-out will automatically reset when the motor temperature has returned to within the motor's operating limits. Failure or damage to electronics components may require repair or replacement of such components or the entire product.

#### Fan replacement

- 1. Determine which of the fans is not functioning.
- 2. Disconnect the cables from the relevant fan.
- 3. Remove the screws securing the fan and lift the fan out.
- 4. Install the new fan as above in reverse order.

#### **Replacing the PC board**

- 1. The PC board is located in the terminal box.
- 2. Mark and disconnect the cables to the PC board.
- 3. Unhatch the board from its PCB snap-in spacers and lift out.
- 4. Install the new PC board as above in reverse order.

### Troubleshooting

*If the fans are not running or do not perform properly, check the following:* 

- The power supply.
- That the intake grille/filter is not dirty.
- That the motor's safety cut-out has not been deployed.
- Functions and settings of the FC control system, see the FC manual.

#### *If there is no heat, check the following:*

• Functions and settings of the FC control system, see the FC manual.

## For units with electrical heating, also check the following:

- Power supply to electric heater coil; check fuses and circuit-breaker (if any).
- That the overheat protection has not been deployed.

## For units with a water coil, also check the following:

- That the water coil is vented
- That there is sufficient water flow and pressure.
- That incoming water is heated adequately.
- That the valves and the actuators are correctly installed and working.

If the fault cannot be rectified, please contact a qualified service technician.

#### Residual current circuit breaker (E)

When the installation is protected by means of a residual current circuit breaker, which trips when the appliance is connected, this may be due to moisture in the heating element. When an appliance containing a heater element has not been used for a long period or stored in a damp environment, moisture can enter the element.

This should not be seen as a fault, but is simply rectified by connecting the appliance to the main supply via a socket without a safety cut-out so that the moisture can be eliminated from the element. The drying time can vary from a few hours to a few days. As a preventive measure, the unit should occasionally be run for a short time when it is not being used for extended periods of time.

#### Packaging

Packaging materials are chosen with consideration to the environment and are therefore recyclable.

## Handling of product at end of working life

This product may contain substances necessary for the functionality of the product but potentially dangerous for the environment. The product should not be disposed of mixed with general household waste but delivered to a designated collection point for environmental recycling. Please contact the local authority for further details of your nearest designated collection point.

#### Safety

- For all installations of electrically heated products a residual current circuit breaker 300 mA for fire protection must be used.
- *Keep the areas around the air intake and exhaust grilles free from possible obstructions!*
- The unit must not be fully or partially covered as overheating can result in a fire risk!
- Lifting equipment must be used to lift the unit.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

#### Main office

Frico AB Industrivägen 41 SE-433 61 Sävedalen Sweden Tel: +46 31 336 86 00

mailbox@frico.se www.frico.net

For latest updated information and information about your local contact: www.frico.net

Art.no 253011, 2021-02-16 CH