


This document must not be copied without our written permission, and the contents thereof must not be imparted to a third party nor be used for any unauthorized purpose. Contravention will be prosecuted. SYSTEMAIR AB

Denna handling får ej utan vårt skriftliga medgivande kopieras. Den får ej heller delges annan eller ejst obehörigen användas. Överträdelse härav beivras med stöd av gällande lag. SYSTEMAIR AB



Note! Items drawn with dashed lines are accessories!

Fuse	FR 06 10 kW	FR 08 12 kW	FR 11 15 kW
AS 1	10 A	10 A	10 A
AS 2	16 A	25 A	25 A

Nr. No.	Ant. Pc.	Ändring Amendment	Dat. Date	Sign.	Godk. App.	Nr. No.	Ant. Pc.	Ändring Amendment	Dat. Date	Sign.	Godk. App.

Det.-nr. Part.No.	Ant. Pc.	Benämning Name	Material	Mod.-nr Ämne Dimension	Anm. Note
Konstr. / Design	Ritad / Drawn	Kontr. / Checked	Standard	Godk. / App.	Ersätter / Replaces
	RKH		ISO		1:1
Wiring diagram Topvex FR 06-11 EL 400V 3N~			Art.-nr. / Art.No.		Dot. / Date
			Ritn.nr. / Drawing No.		Rev.
			15209-95		E