


Original instructions

**Kamrörsradiator**  
**Ribbed pipe radiator**  
**Оребренные трубчатые радиаторы**  
**Radiateurs à ailettes**  
**Rippenheizkörper**  
**Ribberørsovn**



SE ... 8

EN ... 10

RU ... 12


FR ... 14

DE ... 16


NO ... 18

Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы  
 Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn


Mått / Dimensions / Основные размеры / Dimensions / Abmessungen / Mål




	A [mm]	B [mm]
<b>125-12B</b>	370	245
<b>125-22B</b>	530	405
<b>125-32B/W/G</b>	730	605
<b>125-42B/W/G</b>	880	755
<b>125-52B/W/G</b>	1185	1060
<b>127-22B</b>	980	855
<b>127-42B</b>	1925	1800



Minimavstånd / Minimum distances / Минимальные расстояния при установке /  
 Distances minimales / Mindestabstände / Minsteavstand



Tillbehör / Accessories / Принадлежности / Accessoires / Zubehör / Tilbehør



FBRP

# Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn

**SE** EU-kommissionens Ecodesignförförordning (EU) 2015/1188 för rumsvärmare skiljer på användningsområden för olika installationer. Förförordningen gäller då installationen är avsedd att skapa värmekomfort för människor som vistas i lokalen. Förförordningen gäller inte för installationer som är avsedda för värmebehov av mer teknisk art såsom grundvärme i maskinrum, värmebehov i produktionsprocesser, frostskydd, etc. Förförordningen gäller heller inte installationer i fordon, offshore eller utomhus.

Många av Fricos produkter kan användas både som rumsvärmare (definierade enligt (EU) 2015/1188) och som värmare för tekniska behov. Vid installationstillfället är det upp till ansvarig installatör att bedöma om Ecodesignförförordningen är applicerbar eller inte. Regleringslösningar för installationer som inte omfattas av Ecodesignförförordningen redovisas i separat tabell.

**EN** Ecodesign Regulation (EU) 2015/1188 concerning local space heaters does not apply to all application areas. The Regulation applies when an installation is intended to provide thermal comfort for people in the premises. The Regulation does not apply to heating installations of a more technical nature e.g. in engineering/utility rooms, in production processes, frost protection, etc. The Regulation also does not apply to installations in vehicles, offshore or outdoors.

Many of Frico's products can be used as both local space heaters (as defined in (EU) 2015/1188) and for technical heating purposes. It is up to the installer responsible for the installation to assess whether the Ecodesign Regulation is applicable or not. Control solutions for installations not covered by the Ecodesign Regulation are listed in a separate table.

**RU** Положения требований Экодизайн (EU) 2015/1188 по приборам локального обогрева не охватывают все возможные области их применения. Требования Экодизайн применяются, когда установка предназначена для обеспечения теплового комфорта людей в помещениях. Эти Требования не распространяются на установки и системы обогрева более сложного технического характера, например, при обогреве технических, служебных и производственных помещений, при организации защиты от замерзания и т. д. Также требования Экодизайн не применяются в случае установки оборудования в транспортных средствах, сооружениях на море и на открытых площадках.

Многие виды оборудования Frico могут применяться как в качестве приборов локального обогрева (как определено нормативами (EU) 2015/1188) так и в качестве составных частей обогревательных систем общественных и производственных зданий. Ответственность за определение необходимости применения или не применения требований Экодизайн несет организация, осуществляющая монтаж данного оборудования. Приборы управления для установок оборудования, не подпадающих под положения требований Экодизайн, перечислены в отдельной таблице.

**FR** La réglementation relative à l'écoconception (UE) 2015/1188 concernant les dispositifs de chauffage décentralisés ne s'applique pas à tous les cas. Elle s'applique lorsqu'une installation est destinée à assurer un confort thermique à des personnes dans les locaux. Elle ne s'applique pas au chauffage d'installations d'une nature plus technique (salles des machines/de service, processus de production, protection contre le gel, etc.). Elle ne s'applique pas non plus aux installations qui se trouvent à bord de véhicules, offshore ou en extérieur.

De nombreux produits Frico peuvent être utilisés comme des dispositifs de chauffage décentralisés (tel que défini dans la réglementation (UE) 2015/1188) et à des fins de chauffage technique. Il appartient à l'installateur de déterminer si la réglementation relative à l'écoconception s'applique ou non. Les solutions de contrôle pour les installations qui ne sont pas couvertes par la réglementation relative à l'écoconception sont présentées dans un tableau distinct.

# Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn

**DE** Die Ökodesign-Verordnung (EU) 2015/1188 über Einzelraumheizgeräte trifft nicht auf alle Anwendungsgebiete zu.

Die Verordnung findet Anwendung, wenn eine Installation dazu bestimmt ist, innerhalb eines Raumes ein für den Menschen angenehmes Temperaturniveau zu erreichen. Die Verordnung findet keine Anwendung auf Heizungsinstallationen technischer Natur, z. B. in Technik-/Wirtschaftsräumen, bei Produktionsprozessen, für Frostschutz usw. Die Verordnung findet ebenfalls keine Anwendung bei Installationen in Fahrzeugen, Offshoreanlagen und Außenbereichen.

Viele Frico-Produkte können sowohl als Einzelraumheizgerät (gemäß Definition nach (EU) 2015/1188) als auch für technische Heizprozesse eingesetzt werden. Der Monteur, der für die Installation verantwortlich ist, muss beurteilen, ob die Ökodesign-Verordnung anwendbar ist oder nicht. Steuerungslösungen für Installationen, die nicht unter die Ökodesign-Verordnung fallen, sind in einer separaten Tabelle aufgelistet.

**NO** Økodesigndirektivet (EU) 2015/1188 som gjelder varmeovner, gjelder ikke alle bruksområder. Direktivet gjelder når en installasjon har som formål å skape en komfortabel temperatur for personene på stedet. Direktivet gjelder ikke til oppvarmingsinstallasjoner av det mer tekniske slaget, som i produktutviklingsrom, bruksområder, i produksjonsprosesser, frostbeskyttelse etc. Direktivet gjelder heller ikke installasjoner som befinner seg i kjøretøy, offshore eller utendørs.


Mange av Fricos produkter kan brukes både som varmeovner (som definert i 2015/1188) og til formål innen teknisk oppvarming. Det er opp til installatøren som er ansvarlig for installasjonen å vurdere hvorvidt Økodesigndirektivet er gjeldende eller ikke. Reguleringsløsninger for installasjoner som ikke dekkes av Økodesigndirektivet står oppført i en separat tabell.

## Controls


Type	HxWxD [mm]
<b>TAP16R</b>	87x87x53
<b>TEP44</b>	87x87x55
<b>RTX54</b>	82x88x25



TAP16R




TEP44




RTX54

## Controls for installations not covered by the Ecodesign Regulation (EU) 2015/1188


Type	HxWxD [mm]
<b>KRT1900</b>	165x57x60
<b>KRT1901</b>	165x57x60
<b>KRTV19</b>	165x57x60



KRT1900



KRT1901



KRTV19

SE: Regleringar för installationer som inte omfattas av Ecodesign, förordning (EU) 2015/1188

DE: Steuerungen für Installationen, die nicht unter die Ökodesign-Verordnung (EU) 2015/1188 fallen

RU: Приборы управления для установок оборудования, не подпадающих под нормы требований Экодизайн (EU) 2015/1188

FR: Régulations pour les installations non couvertes par la réglementation relative à l'écoconception (UE) 2015/1188

NO: Reguleringsløsninger for installasjoner som ikke dekkes av Økodesigndirektivet (EU) 2015/1188

Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы  
Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn

**Tekniska data**

**Kamrörsradiator 125 IP44**

Typ	Effekt [W]	Spänning [V]	Vikt [kg]
125-12B	200	230V~	2,4
125-22B	375	230V~	3,3
125-32B/W/G	575	230V~	4,5
125-42B/W/G	755	230V~	5,5
125-52B/W/G	1150	230V~	7,5

**Kamrörsradiator 127. För brandfarliga rum (sandfyllda). IP44**

Typ	Effekt [W]	Spänning [V]	Vikt [kg]
127-22B	500	230V~	10,9
127-42B	800	230V~	33,3

**Технические характеристики**

**Модель 125 IP44**

Модель	Мощность [Вт]	Напряжение [В]	Вес [кг]
125-12B	200	230В~	2,4
125-22B	375	230В~	3,3
125-32B/W/G	575	230В~	4,5
125-42B/W/G	755	230В~	5,5
125-52B/W/G	1150	230В~	7,5

**Модель 127 Наполненный песком. IP44**

Модель	Мощность [Вт]	Напряжение [В]	Вес [кг]
127-22B	500	230В~	10,9
127-42B	800	230В~	33,3

**Technische Daten**

**Rippenrohrheizkörper 125 IP44**

Typ	Ausgangsart [W]	Spannung [V]	Gewicht [kg]
125-12B	200	230V~	2.4
125-22B	375	230V~	3.3
125-32B/W/G	575	230V~	4.5
125-42B/W/G	755	230V~	5.5
125-52B/W/G	1150	230V~	7.5

**Rippenrohrheizkörper 127 Für Räume, in denen Brandgefahr besteht (sandgefüllt). IP44**

Typ	Ausgangsart [W]	Spannung [V]	Gewicht [kg]
127-22B	500	230V~	10.9
127-42B	800	230V~	33.3

**Technical data**

**Ribbed pipe radiator 125 IP44**

Type	Output [W]	Voltage [V]	Weight [kg]
125-12B	200	230V~	2.4
125-22B	375	230V~	3.3
125-32B/W/G	575	230V~	4.5
125-42B/W/G	755	230V~	5.5
125-52B/W/G	1150	230V~	7.5

**Ribbed pipe radiator 127. For rooms where there is risk of fire (sandfilled). IP44**

Type	Output [W]	Voltage [V]	Weight [kg]
127-22B	500	230V~	10.9
127-42B	800	230V~	33.3

**Caractéristiques techniques**

**Radiateur à ailettes 125 IP44**

Type	Puissance [W]	Tension [V]	Poids [kg]
125-12B	200	230V~	2.4
125-22B	375	230V~	3.3
125-32B/W/G	575	230V~	4.5
125-42B/W/G	755	230V~	5.5
125-52B/W/G	1150	230V~	7.5

**Radiateur à ailettes 127. Adapté aux locaux à atmosphère critique (risque d'incendie). Rempli de sable. IP44**

Type	Puissance [W]	Tension [V]	Poids [kg]
127-22B	500	230V~	10.9
127-42B	800	230V~	33.3

**Tekniske data**

**Ribberørsovn 125 IP44**

Type	Effekt [W]	Spänning [V]	Vekt [kg]
125-12B	200	230V~	2,4
125-22B	375	230V~	3,3
125-32B/W/G	575	230V~	4,5
125-42B/W/G	755	230V~	5,5
125-52B/W/G	1150	230V~	7,5


**Ribberørsovn 127. For brannfarlige rom (sandfylte). IP44**

Type	Effekt [W]	Spänning [V]	Vekt [kg]
127-22B	500	230V~	10,9
127-42B	800	230V~	33,3


Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы  
Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn

Wiring diagrams

Control by thermostat, 125-12B, 125-22B, 125-32B/W/G, 125-42B/W/G and 127-22B




Control by thermostat, 125-52B/W/G and 127-42B




Kamrörsradiator / Ribbed pipe radiator / Оребренные трубчатые радиаторы  
Radiateurs à ailettes / Rippenheizkörper / Ribberørsovn

Wiring diagrams

Control by thermostat, 125-12B, 125-22B, 125-32B/W/G, 125-42B/W/G and 127-22B.  
Controls for installations not covered by the Ecodesign Regulation (EU) 2015/1188.



Control by thermostat, 125-52B/W/G and 127-42B. Controls for installations not covered by the Ecodesign Regulation (EU) 2015/1188.



## Installation and operating instructions

### General Instructions

Read these instructions carefully before installation and use. Keep this manual for future reference.

*The product may only be used as set out in the assembly and operating instructions. The guarantee is only valid if the product is used in the manner intended and in accordance with the instructions.*

The FRICO ribbed pipe radiators are manufactured by steel pipes with ribbed fins. The ends are constructed in such a way that they can be used as mounting consoles. The radiators have a reset overheat protection of type capillary tube. The reset of the overheat protection is made, after that the reason for the fault has been found and solved, by pressing the reset switch on the inside of the cover. All types are approved for stationary mounting in dry, humid and wet facilities as well as in garages. Furthermore, the sand filled radiators are approved for mounting in rooms where there is a risk for fire. IP44

### Mounting

The radiators are to be horizontally mounted on the wall with 4 screws. As you can see from the existing "key holes". of the mounting supports, the radiator shall be mounted with the connection side to the left, seen from the front. The two lower mounting holes are used to lock the radiator. For min. distances, see the dimension drawing. A floor bracket FBRP is available as an accessory.

### Installation

The ribbed pipe radiator is intended for permanent installation. The installation, which should be preceded by an omnipolar switch with a contact separation of at least 3 mm, should only be wired by a competent electrician and in accordance with the latest edition of IEE wiring regulations.

### Control

When using this product as a local space heater according to Ecodesign Regulation (EU) 2015/1188, it must be supplemented with one of the following approved controls.

- TAP16R, electronic thermostat that includes:

- Electronic room temperature control plus week timer
- Room temperature control with open window detection
- Adaptive start control

The product can be controlled in a different way, e.g. by an overall control system (BMS), but in that case the responsibility lies with the installer to ensure that the control system is programmed to make the installation meet the requirements of Ecodesign Regulation (EU) 2015/1188.

### Start-up

When the unit is used for the first time or after a long period of disuse, smoke or odour may result from dust or dirt that has collected on the element. This is completely normal and disappears after a short time.

### Packaging

Packaging materials are chosen with consideration to environment and are therefore recyclable.

### Handling of product at end of working life

This product may contain substances necessary for functionality of product but potentially dangerous for the environment. The product should not be disposed mixed with general household waste but delivered to a designated collection point for environmental recycling. Please contact local authority for further details of your nearest designated collection point.



**Safety**

- *For all installations of electrically heated products should a residual current circuit breaker 300 mA for fire protection be used.*
- *The unit may have hot surfaces during operation and when cooling down!*
- *The unit must not be fully or partially covered with clothing, or similar materials, as overheating can result in a fire risk!*
- *The unit must not be placed directly under fixed wall sockets!*
- *This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.*
- *Children of less than 3 years should be kept away unless continuously supervised.*
- *Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.*
- *Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.*

**CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.**



**Main office**

Frico AB  
Industrivägen 41  
SE-433 61 Sävedalen  
Sweden

Tel: +46 31 336 86 00

mailbox@frico.se

www.frico.net

**For latest updated information and information  
about your local contact: [www.frico.net](http://www.frico.net)**